



INDUSTRIAL FLOOR TAPE INSTRUCTIONS

1. Ensure floor is completely dry, clean, and free of contaminants such as oils, grease, sand, dirt, dust, curing compounds, mud, and salts. We recommend cleaning the floor with a light detergent & water, or alcohol.

2. Peel backing off tape and apply to floor surface.

3. Firmly and slowly tamp the product in the same direction as it was initially applied. Use a tamper device (with a minimum 200 lb load and a tamping surface at least 2" wider than the tape being used) or slowly drive a heavy piece of machinery, such as a forklift, down the entire run.

- All users should test a small piece of product in an inconspicuous location to ensure good results prior to installing large portions.
- Do not apply product directly on old tape or aisle paint, seams, joints, deteriorating marking or substrates.
- Do not overlap tape- instead use butt splices.
- We recommend tapes applied over seams and joints should be cut back 1" on either side of the joint/seam so as to not leave a gap under the material where air/moisture could potentially de-bond areas of tape.
- If removal is required, place a small flat blade such as a scraper blade underneath tape and pry up an end of tape, then pull tape slowly in a upward direction at a 90° angle. If tape has not been damaged, material will be removeable intact or in large pieces.

Other great items you may find useful:

- 5S Red Tags
- Custom Foam Tool Kits
- 5S and Safety Training DVD's
- Tool Tracer Shadowboard Vinyl
- 5S Vinyl Multipurpose Tape
- 5S Corner Markers
- Custom Vinyl Signs and Lettering
- Industrial Carpet Tape

and more available at:



5S Vinyl Multipurpose
Tape



Custom Foam Tool
Kits



Tool Tracer
Shadowboard Vinyl

www.CreativeSafetySupply.com
toll-free: (866) 777-1360

Call us or visit us online
for all your 5S needs!

